

TWO YEAR WARRANTY

Dateline Imports Pty Limited guarantees your appliance against any defect arising from faulty workmanship or materials within 24 months from the date of purchase subject to the following conditions:

1. The manufacturer's operating and maintenance instructions for the appliance have been complied with.
2. This guarantee does not cover bulbs, normal wear and tear or damage, including the cord, resulting from the use of incorrect voltage, negligence, accidents, alteration or damage to the cord resulting from being wrapped around the appliance.

Important: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major repair.

Should your appliance require servicing under this guarantee, the appliance together with proof of purchase (invoice/receipt), are to be returned to your place of purchase or Dateline Imports P/L.

REMOVE PLASTIC PROTECTIVE FILM FROM THE DRYER HANDLE AND BARREL PRIOR TO USING DRYER.

DO NOT WRAP THE CORD AROUND THE BODY OF THE APPLIANCE. THIS MAY EVENTUALLY CAUSE A KINK IN THE CORD AND POSSIBLY DAMAGE THE CORD. COIL CORD LOOSELY AND PLACE IT ALONG SIDE YOUR APPLIANCE WHEN NOT IN USE.

iQ perfetto

Distributed by Dateline Imports P/L
8/1801 Botany Road Banksmeadow
NSW 2019 Australia
Tel: 02 9666 3611

Dateline Imports Ltd
66 Apollo Drive Albany
Auckland 0632 New Zealand
Tel: 0800 169 600

CAUTION

READ CAREFULLY BEFORE USING THE PRODUCT

YOU HAVE ACQUIRED A HAIRDRYER WITH PROFESSIONAL TECHNOLOGY DEVELOPED BY GAMA. PROFESSIONAL.

THE IQ HAIRDRYER HAS A MICRO FILTER SPECIALLY DESIGNED TO PREVENT HAIR, HAIRSPRAY AND DUST FROM ENTERING THE DRYER MOTOR.

CAUTION

WHEN HAIR, HAIRSPRAY OR DUST IS DEPOSITED ON THE REAR FILTER AND INTERFERES WITH AIRFLOW INTO THE DRYER THE DRYER WILL AUTOMATICALLY SWITCH OFF. WHEN THIS OCCURS TWO WHITE LIGHTS WILL APPEAR ON THE DRYER HANDLE.



TO CLEAN THE DRYER FILTER

1. REMOVE REAR FILTER BY ROTATING THE METAL RING CAREFULLY IN A COUNTERCLOCKWISE DIRECTION. THE REAR FILTER ('B') WILL THEN COME OFF THE DRYER
2. CLEAN THE FILTER WITH A BRUSH OR A CLOTH TO REMOVE ALL THE DEBRIS FROM THE FILTER
3. REASSEMBLE. THE HAIR DRYER WILL THEN BE READY TO US

THIS SHOULD BE DONE DAILY IN PROFESSIONAL USE. IN DOMESTIC USE IT CAN BE DONE WEEKLY.

AUTO CLEANING

1. ENSURE DRYER HAS COOLED DOWN
2. REMOVE THE REAR FILTER BY ROTATING THE METAL RING CAREFULLY IN A COUNTERCLOCKWISE DIRECTION (PICTURE 1)
3. REMOVE ANY NOZZLE OR DIFFUSER IF ATTACHED THEN TURN ON THE HAIRDRYER FOR A FEW SECONDS BY SWITCHING THE ON SWITCH TO POSITION 1 (PICTURE 1) .
4. TURN OFF THE HAIRDRYER (PICTURE 1) THEN PRESS THE TOP OF THE AIRFLOW SWITCH LOCATED ON THE SIDE OF THE DRYER FOR 7 SECONDS (PICTURE 2)
5. THE DRYER WILL THEN AUTOMATICALLY BLOW AIR IN A REVERSE DIRECTION. THIS WILL REMOVE DEBRIS FROM THE REAR FILTER. THE SELF-CLEANING CYCLE LASTS 15 SECONDS. DO NOT PRESS ANY SWITCH DURING THIS PROCESS THE DRYER WILL AUTOMATICALLY STOP. THE DRYER IS THEN READY TO USE



IMPORTANT WEEKLY MAINTENANCE

REMOVE THE REAR FILTER AS DESCRIBED ABOVE AND THE ROUND COVER OVER THE INTERNAL MICRO FILTER. BRUSH THE INTERNAL MICRO FILTER WITH A BRUSH OR A CLOTH TO REMOVE ALL DEBRIS.